30801

ROLL PAN HARNESS
INSTALLATION INSTRUCTIONS

1. INSERT BULBS INTO LIGHT SOCKETS. BE CAREFUL TO LINE UP TABS ON BULBS. BULBS SHOULD ONLY FIT ONE WAY.

2. INSERT LIGHT SOCKETS INTO THEIR RESPECTIVE HOUSINGS BY LINING UP THE WIDEST OF THE THREE LOCKING TABS TO THE WIDEST SLOT IN THE HOUSING-PUSH IN, THEN TURN CLOCKWISE TO LOCK.

3. CONNECT THE 4 WIRE PLUG TO THE MATING HALF ON THE CHASSIS HARNESS. BY FIRST DISCONNECTING EXISTING TAIL LIGHT HARNESS AT LEFT REAR FRAME RAIL.

4. CONNECT THE BLACK WIRE TO GROUND.

5. CONNECT THE LT.GREEN WIRE TO THE BACKUP LIGHT FEED WIRE IN FACTORY ORIGINAL HARNESS. (IF NECESSARY)

6. CONNECT BROWN POWER WIRE TO THE WIRE ON THE LICENSE PLATE LIGHT(CONNECT BLACK WIRE TO THE GROUND WIRE ON THE LICENSE PLATE LIGHT IF APPLICABLE, OTHERWISE TAPE & STORE THIS BLACK WIRE).