30804

WIPER/HEADLIGHT RELAY INSTALLATION INSTRUCTIONS

1. LOCATE AND MOUNT THE RELAY ASSEMBLY UNDER THE DASH WITH THE SCREW PROVIDED.

   NOTE: THE SMALL BLACK WIRE SHOULD BE ATTACHED WITH THE SAME SCREW IN ORDER TO GROUND THE RELAY.

2. AT THE DIMMER SWITCH, LOCATE THE LOW BEAM WIRE AND CUT IT 3" TO 6" FROM DIMMER SWITCH.

3. WITH THE BUTT CONNECTOR PROVIDED, ATTACH THE WIRE MARKED ADIMMER@ TO THE END OF THE CUT WIRE ON THE DIMMER SWITCH SIDE.

4. WITH THE BUTT CONNECTOR PROVIDED, ATTACH THE WIRE MARKED ALOW@ BEAM TO THE END OF THE CUT WIRE GOING TO THE LOW BEAM HEADLIGHTS.

5. ATTACH THE RED 14 GAUGE WIRE TO A FUSED CIRCUIT SUCH AS THE HEADLIGHT SWITCH CIRCUIT AT THE FUSE BLOCK.

6. ATTACH THE BLUE 18 GAUGE WIRE TO THE WIPER SWITCH POWER TERMINAL (WHERE THE WIRE TO THE WIPER MOTOR IS ATTACHED).